



METAL-FACH



BALE WRAPPER

Z577

INSTRUCTIONS MANUAL – PART I

TRANSLATION OF THE ORIGINAL INSTRUCTIONS MANUAL

REVISION I

NOVEMBER 2018



EC DECLARATION OF CONFORMITY

The undersigned,	Jacek Kucharewicz, President of the Board,	
hereby declares, with full responsibility, that the complete machine		
BALE WRAPPER		
1.1.	Brand (the trading name of the manufacturer)	Metal-Fach
1.2.	Type	Z312
1.2.1.	Variant	
1.2.2.	Version	
1.2.3.	Trade name(s) (if any)	Z577
1.3.	Category, Subcategory and Vehicle Speed Indicator	S1a
1.4.	Company name and manufacturer's address	Metal-Fach sp. z o.o. ul. Kresowa 62 16-100 Sokółka, Poland
1.4.2.	Name and address of the authorised representative of the manufacturer (if applicable)	N/A
1.5.1.	Location of the rating plate of the manufacturer	On the right-hand side of the main frame of the machine
1.5.2.	Method used to fix the rating plate of the manufacturer	Bonded
1.6.1.	Location of the vehicle-identification number on the chassis	
2.	Machine identification number	
<p>complies with all the appropriate regulations of Directive 2006/42/EC and the Regulation of the Minister of the Economy dated 21 October 2008 on the principal requirements for machines (Journal of Laws of 2008, No. 199, item 1228, as amended)</p> <p>The following harmonised standards were applied to assess the compliance. <u>PN-EN ISO 4254-1: 2016-02, PN-EN ISO 13857: 2010, PN-EN ISO 12100: 2012</u> and standards PN-ISO 3600:1998, PN-ISO 11684:1998 and the Regulation of the Minister of the Infrastructure dated 31 December 2002 on the technical conditions of vehicles and the range of their essential equipment (Journal of Laws of 2003, No. 32, item 262, as amended).</p> <p>Safety Testing Report No.: MF/5/2010</p> <p>This EC Declaration of Conformity shall become null and void if the machine is modified or reconstructed without the Manufacturer's consent.</p>		

Sokółka
(Place)

27/11/2010
(Date)

Jacek Kucharewicz
(Signature)

President of the Board
(Position)

Machine data

Type of machine

Bale Wrapper

Type designation

Serial Number⁽¹⁾:

Machine
manufacturer

METAL-FACH Sp. z o.o.
16-100 Sokółka
ul. Kresowa 62
Phone (0-85) 711 98 40
Fax: (0-85) 711 90 65

Seller

Address

Phone/Fax

Delivery date

Owner or user

Name

Address

Phone/Fax

⁽¹⁾The data are located on the machine's rating plate located on the front part of the machine's main frame

Table of contents

PART I

EC DECLARATION OF CONFORMITY	3
INTRODUCTION	9
1. General description	11
1.1 Introduction.....	11
1.2 Bale Wrapper Identification.....	11
1.3 Intended use.....	13
1.4 Bale Wrapper design	15
1.5 Wrapper characteristics	16
1.6 Bale Wrapper dimensions.....	18
1.7 Location of pictograms.....	19
1.8 Hazard warning symbols.....	20
2. Safety of use	23
2.1 Obligation to provide information	23
2.2 General safety principles	23
2.3 Use with a tractor.....	26
2.3.1 Connection with drive.....	28
2.3.2 Drive disconnection.....	30
2.4 Drawbar components.....	31
2.5 Lighting system.....	32
2.6 Hydraulic system	33
2.7 Start-up.....	35
2.7.1 Counter start-up.....	37
3. Ongoing control and adjustment components.....	38
3.1 Arrangement of the ongoing adjustment controls	38
3.2 Control levers	39
3.3 Film feeder.....	40
3.4 Support foot.....	41
3.5 Adjusting the hitch height.....	42
3.6 Shifting the ground wheel position	43
3.6.1 Unlocking the axle shaft position	43
3.6.2 Locking the axle shaft position	43
3.6.3 Ground wheel service position	44

3.6.4	Ground wheel transporting position.....	45
3.7	Ground wheel hydraulic shifting set	46
3.8	Adjusting the bale tipper width	47
3.9	Adjusting the height of the revolution counter sensor	47
3.10	Adjusting the loading arm width.....	48
3.11	Adjusting the tension of the chains.....	49
3.11.1	Adjusting the drive chain tension for the service table	49
3.11.2	Adjusting the drive chain for the rollers of the service table	50
3.11.3	Adjusting the film feeder chain drive.....	51
3.12	Adapting the wrapping for 500 mm film	52
3.12.1	Adapting the service table chain drive for 500 mm film.....	52
3.12.2	Adapting the feeder for 500 mm film	52
3.13	Adjustment valves	53
3.13.1	Adjustment valve for the turntable lock.....	54
3.14	Adjusting the mechanical film cutting device	55
3.15	Adjusting the hydraulic film cutting device	57
3.15.1	Adjusting the cutter height.....	57
3.15.2	Adjusting the film cutter activation position	58
3.15.3	Filling the hydraulic accumulator	59
3.16	Front lighting transporting and service positions.....	60
	INDEX OF NAMES AND ABBREVIATIONS	61
	ALPHABETICAL INDEX	62
	NOTES	64

PART II

- 4. Bale-Wrapper operation **Błąd! Nie zdefiniowano zakładki.**
 - 4.1 Preparing bales **Błąd! Nie zdefiniowano zakładki.**
 - 4.2 Film installation..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.3 Wrap Counter **Błąd! Nie zdefiniowano zakładki.**
 - 4.3.1 Switching the counter on and off **Błąd! Nie zdefiniowano zakładki.**
 - 4.3.2 Rotation sensor..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.3.3 Setting the wind number **Błąd! Nie zdefiniowano zakładki.**
 - 4.3.4 Wrap-number calculating method..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.3.5 Selecting fields..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.3.6 Counting-mode operation..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.4 Working position **Błąd! Nie zdefiniowano zakładki.**
 - 4.5 Servicing cycles of the Bale Wrapper..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.5.1 Bale loading **Błąd! Nie zdefiniowano zakładki.**
 - 4.5.2 Wrapping **Błąd! Nie zdefiniowano zakładki.**
 - 4.5.3 Unloading the wrapped bale..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.5.4 Mechanical film cutting..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.5.5 Hydraulic film cutting..... **Błąd! Nie zdefiniowano zakładki.**
 - 4.6 Film breaking **Błąd! Nie zdefiniowano zakładki.**
 - 4.7 End of operation – the Bale Wrapper transporting position **Błąd! Nie zdefiniowano zakładki.**
- 5. Operation and maintenance activities..... **Błąd! Nie zdefiniowano zakładki.**
 - 5.1 Cleaning **Błąd! Nie zdefiniowano zakładki.**
 - 5.2 Machine maintenance..... **Błąd! Nie zdefiniowano zakładki.**
 - 5.3 Scheduled Inspections..... **Błąd! Nie zdefiniowano zakładki.**
 - 5.4 Metrical-bolt tightening torques **Błąd! Nie zdefiniowano zakładki.**
 - 5.5 Lubrication interval..... **Błąd! Nie zdefiniowano zakładki.**
 - 5.6 Lubrication points..... **Błąd! Nie zdefiniowano zakładki.**
- 6. Authorised service..... **Błąd! Nie zdefiniowano zakładki.**
 - 6.1 Guarantee service **Błąd! Nie zdefiniowano zakładki.**
 - 6.2 Routine service..... **Błąd! Nie zdefiniowano zakładki.**
 - 6.3 Ordering spare parts..... **Błąd! Nie zdefiniowano zakładki.**
- 7. Wrapper transporting..... **Błąd! Nie zdefiniowano zakładki.**
 - 7.1 Road-Traffic Participant **Błąd! Nie zdefiniowano zakładki.**

7.1.1	The Bale tipper's transporting position	Błąd! Nie zdefiniowano zakładki.
7.1.2	Securing the loading arm	Błąd! Nie zdefiniowano zakładki.
7.2	The Tractor's and Bale-Wrappers stability	Błąd! Nie zdefiniowano zakładki.
7.3	Load transporting.....	Błąd! Nie zdefiniowano zakładki.
8.	Wrapper storage	Błąd! Nie zdefiniowano zakładki.
9.	Residual Risk	Błąd! Nie zdefiniowano zakładki.
9.1	Residual-risk descriptions	Błąd! Nie zdefiniowano zakładki.
9.2	The Assessment of Residual Risk	Błąd! Nie zdefiniowano zakładki.
10.	Wrapper disposal	Błąd! Nie zdefiniowano zakładki.
11.	Typical faults and troubleshooting	Błąd! Nie zdefiniowano zakładki.
12.	Accessories.....	Błąd! Nie zdefiniowano zakładki.
	INDEX OF NAMES AND ABBREVIATIONS	Błąd! Nie zdefiniowano zakładki.
	ALPHABETICAL INDEX	Błąd! Nie zdefiniowano zakładki.
	NOTES	Błąd! Nie zdefiniowano zakładki.

INTRODUCTION

The information included in the Instructions Manual is valid as of the date of issue. The manufacturer reserves its right to make design changes to machines and, due to this fact, some values or illustrations might not correspond to the actual state of the machine supplied to the user. The manufacturer reserves its right to make design changes without amending this Instructions Manual. The Instructions Manual is part of the basic equipment of the machine. The User is obliged to read the contents of this Instructions Manual and comply with the recommendations included in it, before using the machine. It will ensure safe operation and a trouble-free machine operation.

The machine has been built in compliance with the standards in force and the current legal provisions. The Manual describes principal safety and operation rules for the Metal-Fach Bale Wrapper.

The significant obligations of the Manufacturer are shown in the Guarantee Certificate, which includes the complete regulations currently in force regarding guarantee services.

If the information included in the Instructions manual prove to be incomprehensible, you should address the seller where the machine was purchased or the manufacturer directly for assistance.

The spare-parts catalogue functions as a separate list and is attached in the form of a CD during the machine purchase, and also is available on the Manufacturer's website: www.metalfach.com.pl

Pursuant to the Act of 4 February 1994 on copyrights and related Laws (Journal of Laws of 2018, item 1191), this Instructions Manual is protected by copyright. It is prohibited to copy and distribute the contents and figures without the consent of the proprietor of the copyright.

The Guarantee Certificate, together with the warranty terms, is attached to this Instructions Manual as a separate document.

Manufacturer address

Metal-Fach sp. z o.o.

ul. Kresowa 62

16-100 Sokółka

Telephone

Phone (0-85) 711 98 40

Fax (0-85) 711 90 65

The symbols used in this Instructions Manual



DANGER

Hazard-warning symbol. It indicates the occurrence of a serious hazard condition, which, if not avoided, can result in death or serious injury. The symbol warns against the most-dangerous situations.



CAUTION

This symbol points to especially important information and recommendations. Non-compliance with the described recommendations risks serious damage to the machine due to its incorrect operation.



WARNING

This symbol indicates the possibility of the occurrence of a hazard, which, if not avoided, can result in death or serious injury. This symbol indicates a lower level of risk of injury than the symbol including the word "DANGER".



This symbol indicates useful information.



This symbol indicates maintenance activities which should be performed periodically.

1. General description

1.1 Introduction

THE INSTRUCTIONS MANUAL IS PROVIDED WITH THE BASIC EQUIPMENT OF THE BALE WRAPPER

To operate the Bale Wrapper in a safe manner, read and adhere to all the INSTRUCTIONS set out in this Instructions Manual. Abiding by the guidelines provided in the Instructions Manual ensures safe operation for the User and also prolongs the service life of the machine.

1.2 Bale-Wrapper Identification

Identify the Bale Wrapper on the basis of the rating plate permanently fixed to the Bale Wrapper main frame.

The data printed on the rating plate are shown in the figure below.




Figure 1. Example of a rating plate



CAUTION

CAUTION!

Operating the Bale Wrapper on public roads without the rating plate or with an illegible rating plate are prohibited.



When purchasing, make sure that the factory number printed on the machine's rating plate and the number provided in the Instructions Manual and Guarantee Certificate are the same – it is crucial for recognising the guarantee.

When contacting the technical service, the seller, or the Manufacturer, the User is obliged to provide the information included on the machine's rating plate.



The Instructions Manual constitutes the basic equipment of the Z577 Bale Wrapper.

In the event of selling the machine to another user it is obligatory to provide the Instructions Manual. It is recommended for the Bale-Wrapper supplier to archive the Instructions Manual receipt confirmation by the purchaser, submitted with the machine to the new user.

Please read the Instructions Manual carefully!

If you follow its recommendations, it will be possible to operate the machine efficiently and productively, avoid hazards, and maintain the warranty for the duration granted by the Manufacturer. Detailed explanations regarding the design, functioning, operating principles, and any other matters related to the machine, can be provided by the dealers/manufacturer of the Bale Wrapper.



CAUTION

CAUTION!

It is prohibited to use the Wrapper by the persons who have not read this Instructions Manual.

1.3 Intended use

The Z577 Bale Wrapper is a tractor towed machine, working in one line with the tractor, designed for lifting compressed bales of grass, hay or other non-lignified plants from the soil, by means of a loading arm, and loading bales onto the rotary service table. Then the machine wraps the loaded bale with film intended for silage, which is charged on the film feeder, on the machine frame. After finishing wrapping the film is caught and cut off by the film cutter. The last stage is the unloading of the wrapped-up bale onto the ground.

All the work actions must be by one person - an operator who is on the tractor's seat. The Bale Wrapper is fitted with manual control levers which are installed on a tractor for the time of operation.

No cargo, goods, people or animals may be transported by the Bale Wrapper. It is prohibited to transporting bales on the Bale Wrapper on public roads.

The Bale Wrapper may not be used for wrapping or catching/lifting other materials than the plant material bales.

Films or other materials intended by the manufacturer for applications other than wrapping up bales from plant materials may not be used for wrapping with the Bale Wrapper.

Adhere to Bale Wrapper's intended use. which is coupling it with farm tractors with a power of over 30 kW and a min. pull class of 0.9, which meet the combination stability requirements.

During operation, the operator of the Bale Wrapper is not exposed to noise causing loss of hearing, since the noise level of a running machine does not exceed 70 dB (A) and the operating position is located inside the tractor cab.

During operation, the operator of the Bale Wrapper is not exposed to vibrations, since the level of vibrations on the upper limbs of the operator does not exceed 2.5 m/s², while the vibrations on the body are below 0.5 m/s², and the operating position is located inside the tractor cabin.

Detailed explanations regarding the design, functioning, operating principles, and any other matters related to the machine can be provided by authorised dealers/manufacturers of the Bale Wrapper.



The machine is intended for use exclusively for agricultural purposes as described in these Instructions. Any other use of the Bale Wrapper is considered to be non-compliant with its intended use and releases the manufacturer and distributor from their responsibility for damage arising as a result of incorrect use.



CAUTION

CAUTION!

Unauthorised construction changes and working with the Bale Wrapper non-compliant with its intended use and avoiding the safety principles release the manufacturer from responsibility for any resulting hazards and damages.

1.4 Bale-Wrapper design

The Z577 Bale Wrapper is constructed of the following units (Fig. 4):




Figure 4. Wrapper design 1 – Main frame, 2 – Film feeder, 3 – Moving frame, 4 – Rotary frame, 5 – Loading arm, 6 – Drawbar, 7 – Support foot, 8 – Cutting unit, 9 – Side cone, 10 – Rotating axle shaft, 11 – Fixed-axle shaft, 12 – Hydraulic manifold, 13 – Control levers 14 – L-02 Counter, 15 – Bale tipper

Fixed to the main frame (1) is a hitch drawbar (6) used for coupling the Bale Wrapper with the farm tractor, and its levelling in both the working and transporting positions.

The main frame (1) has an articulated joint with the moving frame (3) which is joined with the rotary frame (4). The bale-loading arm (5) and the bale tipper (5) are fixed to the main frame (1) by means of an articulated joint. The main frame (1) is fitted with the film feeder (2) and an adjustable support foot (7). The rotary frame (4) is supplied with the cutting unit (8) and side cones (9) which prevent bales from sliding down. The rotating axle shaft (10) with a ground wheel was fitted on the right-hand side of the main frame (1), and the fixed axle shaft (11) on its left-hand side.

The control components include the hydraulic manifold (12) linked with the control levers (13) by means of ropes. The L-02 counter (14) is used for overseeing the work status, and is ultimately put in the tractor's cab along with the control levers (13).

1.5 Wrapper characteristics

Table 1. Wrapper characteristics

No.	Detailed list	
1.	Type of vehicle	Bale Wrapper
2.	Manufacturer	METAL-FACH Sp. z o.o., 16-100 Sokółka, ul. Kresowa 62
3.	Type	Z312
4.	Trade name	Z577
5.	The location of the rating plate	Front part of the main frame of the machine
6.	Chassis type	Single axle
7.	The way of connecting with the tractor	Towed
8.	Connected with the tractor by	Hitch
9.	Length, mm	min. 4,030; max.: 4,770
10.	Width, mm	min. 2,350; max.: 2,500
11.	Height, mm	min. 21200; max.: 2,450
12.	No. of axes:	2 axle shafts
13.	Distance between the coupling point and the first axle, mm Right axle shaft, mm	min. 3,305; max.: 3,355 min. 3,640; max.: 369.0
14.	Wheel track, mm	min. 2,000; max.: 2,100
15.	Drawbar-eye diameter, mm	44
16.	Maximum tractor hitch pressure, kN	4.2
17.	Machine weight, kg	1,200
18.	Maximum bale weight, kg	800
19.	Bale length, mm	1,200
20.	Bale diameter, mm	1,000-1,200
21.	Tyres	10.0/80 – 12 10PR
22.	Tyre pressure, bar	3.5
23.	Maximum service speed, km/h	10
24.	Maximum transporting speed, km/h	40
25.	Tractor pull class	0.9
26.	Minimum tractor power, kW	30
27.	Required pressure in tractor hydraulic actuator system, MPa	14
28.	Recommended capacity of tractor pump, l/min	25
29.	Wrapper drive	Hydraulic from the tractor's power hydraulics
30.	Rotary frame drive	Hydraulic motor
31.	Max. rotary-frame speed, rpm	35
32.	Bale-loading method	Self-loading arm

33.	Bale-unloading method	Self-unloading unit
34.	Film cutting	Automatic, during unloading
35.	Film width, mm	500; 750
36.	Bale-wrapping time, min.	~2
37.	Number of operators	1 (tractor operator)
38.	Wrap Counter	Electronic, type L-02
39.	Electrical-system voltage, V	12



CAUTION

CAUTION!

The maximum transporting speed of the Bale Wrapper is restricted by the speed index of the tyres mounted (**Tab. 2**) and shall not be higher than 40 km/h.

Table 2. Index indicated on tyres

Tyre marking	Max. allowed speed
A1	5 km/h
A2	10 km/h
A3	15 km/h
A4	20 km/h
A5	25 km/h
A6	30 km/h
A7	35 km/h
A8	40 km/h

1.6 Bale Wrapper dimensions

The overall Bale-Wrapper dimensions in the transporting position are shown in the drawings:




Figure 5. Wrapper dimensions – front




Figure 6. Wrapper dimensions – side

1.7 Location of pictograms




Figure 7. Arrangement of pictograms – right-hand side




Figure 8. Arrangement of pictograms – left-hand side

1.8 Hazard-warning symbols

Warning pictograms located on the machine (**Section 1.7**) inform the operator on hazards and risks which can occur during the operation of the machine. Ensure that the symbols are clean and legible.

Illegible symbols should be replaced with new ones available for purchase at the manufacturer.

Table 3. Pictogram list

No.	Warning symbol (sign)	Meaning
1.		Attention. Before you start operating the machine, read the Instructions Manual.
2.		Attention. Before starting work or repairs, stop the tractor's engine, take the key from the ignition switch.
3.		Attention. Keep away from the links of the Bale Wrapper at work.
4.		Attention. Do not open or remove protective guards during machine operation.
5.		Attention. Do not touch revolving components of the machine at work.
6.		Attention. Keep away from the machine during operation Risk of being crushed by a bale
7.		Attention. Keep a safe distance from raised arms. Danger of crushing

8.		Attention. Danger zone Before starting operation, fit the support
9.		Attention. Crushing hazard.
10.		Attention. Avoid contact with liquid under pressure.
11.		Attention. Do not travel on platforms or ladders.
12.		Attention. Finger-crushing hazard.
13.	<p>UWAGA! ZABRANIA SIĘ PRZEBYWANIA OSÓB POSTRONNYCH W POBLIŻU PRACY MASZINY</p>	Warning inscription Attention. Bystanders standing within the machine operation range are prohibited.
14.	<p>UWAGA! OSTRY NÓŻ</p>	Warning inscription Attention. Sharp blade.
15.		Dimensions of the board: 40x240.
16.		Wearing safety gloves to operate the machine is mandatory.
17.		Pictogram informing on Hooking or lifting point.

18.		Pictogram informing on Film-mounting procedure.
19.		Information pictogram. Proper attachment of the bale-counter sensor under a magnet.
20.		Recommended tyre pressure for the Bale Wrapper.
21.		Pictogram informing on CE marking - manufacturer's conformity declaration on the complying of the machine with the European Union Directives.
22.		Jack-attachment point.
23.		Lubrication point.

2. Safety of use

2.1 Obligation to provide information



CAUTION

CAUTION!

When being sold to a different user, the Bale Wrapper must be handed over together with the Instructions Manual, and the person purchasing the machine must undergo training, according to the guidelines provided herein.

2.2 General safety principles

1. As well as the information included in the Instructions Manual, all the principles and local legal regulations related to safety of work and machine disposal must be met.
2. The Bale Wrapper may only be operated by an adult with valid licence for driving farm tractors, and proper knowledge of health-and-safety regulations with regard to agricultural-equipment operation, provided that they have read and understood this Instructions Manual.
3. Read thoroughly and understand this Instructions Manual and observe its recommendations, paying close attention to the Instructions concerning the safe operation of the Bale Wrapper.
4. The Instructions indicate the machine elements constituting potential hazards. Dangerous places are marked on the machine with yellow labels with warning pictograms. Special attention should be paid to the dangerous places and recommendations should be strictly adhered to.
5. You should learn the meaning of the pictograms which appear.
6. Operating the Bale Wrapper without protective guards in place is strictly prohibited.
7. Prior to each starting of the Bale Wrapper check the machine condition, completeness, and mounting of the guards.
8. Prior to each departure, start-up or ride on public roads, check the correctness of the machine's connection with the tractor, tightening of the wheels, and correct drawbar and tractor connections.
9. Riding the Bale Wrapper on public roads is allowed only in the transporting position having locked the bale tipper.
10. All the adjustment, repair, and service works should be implemented with the tractor's engine off, making sure beforehand that it is protected in the right way against accidental starting up.
11. Prior to commencement and during the loading of bales make sure that there are no by-standers, and especially children.
12. During the operation of the Bale Wrapper provide free space in the zone of the rotating parts. During the switching of the machine to the operating or transporting positions, and the wrapping of bales, there can be no people or animals in the zone of the rotating parts.
13. Never leave the machine unattended during operation.
14. Take special care during operation on inclined terrain. Pay special attention to the possibility of bales' rolling down.
15. It is strictly forbidden to operate the Bale Wrapper under raised machine units.

16. It is strictly forbidden for any person to stay between the tractor and the Bale Wrapper during tractor-engine operation.
17. Take particular care when connecting and disconnecting the Bale Wrapper to and from the tractor. The machine must be connected to a tractor equipped with an agricultural hitch withstanding a higher vertical load than the vertical load on the Bale Wrapper drawbar (**Section 1.5**).
18. During operation, wear the appropriate work clothing and footwear with non-slip soles.
19. Bale-wrapping film should be charged with the tractor engine switched off and protected against accidental starting up (key removed from the ignition and parking brake engaged).
20. It is forbidden to use damaged power hydraulics hoses. Immediately replace damaged hoses with new ones. Impermeable protective clothing and gloves must be worn and the environment must be protected from oil contamination while replacing hoses.
21. Control the power hydraulics installation from the tractor operator's cockpit only.
22. Traffic Law and manufacturer's recommendations must be observed during transporting on roads (**Section 7.1**).
23. Prior to entrance onto public roads provide visual control of the transported machine.
24. It is forbidden to climb onto the Bale Wrapper during its transporting and operation.
25. It is forbidden to climb onto the components of the Bale Wrapper during parking, transporting, and operation.
26. During transporting on the public roads it is forbidden to carry on the Bale Wrapper swathe or hay silage bales.
27. While driving the Bale Wrapper on public roads, the user must use the road lighting installed on the Bale Wrapper in compliance with the local regulations in force.
28. It is forbidden to work with the Bale Wrapper under the influence of alcohol.
29. It is forbidden to operate the Bale Wrapper by persons under the influence of narcotic or medicines with a narcotic reaction
30. It is forbidden to operate the machine by the people under the influence of medicines with a negative influence on the ability to drive vehicles, and general psychophysical efficiency and medicines causing disturbances of concentration or delay in reaction time.
31. It is forbidden to operate the Bale Wrapper in an exhausted state which can cause disturbances of concentration and delay of the reaction time.
32. It is forbidden to drive the Bale Wrapper near sources of open fire.
33. The firefighting regulations must be strictly obeyed and the hazards arising during the operation or stoppage of the Bale Wrapper must be eliminated immediately.
34. The sources of fire must be eliminated using a dry-powder fire extinguisher.
35. During the operation of the Bale Wrapper do not approach it with an open flame and do not smoke near the machine.
36. Before each ride to working, check the tractor is equipped with a dry-powder fire extinguisher. If there isn't one, provide the tractor with one.
37. When failure occurs or a malfunction is discovered on the machine, switch off the tractor's hydraulic system. Stop the tractor's engine, take the key from the ignition, and engage the auxiliary brake. Locate the breakdown or the failure reason and have an authorised service centre remove it.



CAUTION

CAUTION!

Risk of lightning strike during the Bale Wrapper's operation.



The Bale Wrapper comes with a securing chain, padlock, and two sets of keys.



CAUTION

CAUTION!

It is not allowed to leave the farming equipment on slopes or other inclines without securing the vehicle against accidentally rolling away.



CAUTION

CAUTION!

Rotating action is not allowed when

- the loading arm is its raised position
- the moving frame with the service table is in its upper position
- the bale tipper is in its raised transporting position



CAUTION

CAUTION!

Raising the loading arm is not allowed when

- the service table has not been locked in the loading setting
- the moving frame with the service table is in its upper position



CAUTION

CAUTION!

Unloading is not allowed when

- the service table has not been locked in the unloading setting
- the loading arm is its raised position
- the bale tipper is in its raised transporting position

2.3 Use with a tractor

Prior to commencing connecting the bale Wrapper to the tractor make sure that its fulfils all the requirements presented in the machine characteristics (**Section 1.5**) Combine the Bale Wrapper Z577 with a farming tractor with a power of at least 30 kW and a pull class of at least 0.9.

The tractor must be provided with at least two power hydraulics quick-release sockets (acc. to ISO 7241-1, type A, size 12.5), enabling pressure supply and free return of oil from the Bale Wrapper distributor to the tractor's oil tank. The tractor's hydraulic installation must allow the switching off of the hydraulic supply of the working sections from the tractor operator's seat in the tractor's cockpit.

The tractor must be fitted with a 12V power socket with a 10A fuse (lighter socket).

Connect the Bale Wrapper to the lower tractor hitch, which facilitates the transmission of a vertical load of 2.5 kN.

Prior to connecting with the tractor the operator must make sure that the Wrapper is complete and all the bolts are tightened correctly (see **Section 5.4** for the table of bolt-tightening torques).

Make sure that the locations marked as lubrication points really are greased. If this is not the case, have them lubricated. (**Section 5.6**)



DANGER

DANGER!

The machine-working area is considered a danger zone. Before starting the machine ensure there are no persons or animals in the immediate vicinity or around it. Stop the Bale Wrapper immediately if any persons come near the machine. and make any unauthorised persons leave this zone. Never stop in close proximity of or under terraces or balconies, in front of open rooms, or any sorts of platform, where persons or animals can stay. Bale Wrapper's operator is responsible for all damage inflicted by the machine during operation.



CAUTION

CAUTION!

Make sure that in the area of connecting the Wrapper with the tractor and in the near vicinity there are no third parties present, especially children.



WARNING

WARNING!

Wear well-fitting clothes which cannot be caught by movable elements, and boots with non-slip soles.

In the case of the hazard of item ejection wear a protective helmet with eye protection.



CAUTION

CAUTION!

Make sure the power hydraulic system is tight. In order to check that there are no leaks from the hoses use blotting paper or paper.



CAUTION

CAUTION!

Standing near the machine while operating the Bale Wrapper poses a threat of impact or crushing. Exercise special caution during coupling and uncoupling the machine hitch.

2.3.1 Connection with the drive




Figure 9. Connecting the hitch and drive of the Bale Wrapper

- Connect the Bale Wrapper to the lower or upper tractor hitch, which allows the transmission of a vertical load of 4.2 kN. Check the stability and manoeuvrability with the tractor connected (**Section 7.2**).
- Make sure that in the area of Bale Wrapper coupling with the tractor and in the near vicinity there are no bystanders present, children in particular.
- While connecting with the tractor, position the machine along the tractor axis on paved, even, and level ground. Stop the tractor's engine, take the key from the ignition, and engage the tractor's auxiliary brake.
- Level the Bale Wrapper by means of the adjustable support foot and by setting an appropriate hitch height at an appropriate adjustment eye (**Section 3.5**).
- Remove the chain with padlock, which protect the machine against unauthorised use, from the hitch eye (**Section 2.4 – 1**).



CAUTION

CAUTION!

Couple the drawbar eye only with the tractor's agricultural hitch and check the connection for correctness, and the protections for accidental disconnection.

- Start the tractor and drive it towards the Bale Wrapper so that the opening in the hitch eye of the tractor aligns with the opening in the hitch eye of the Bale Wrapper. The opening diameter in the hitch eye is 45 mm.
- Stop the tractor's engine, take the key from the ignition, and engage the parking brake.

- Attach the Bale Wrapper's hitch eye (2) by means of a suitable hitch pin (1), and secure the pin against spontaneous detachment (3).
- Use a chain (4) to provide additional security against detachment of the combination by fastening it between the Bale Wrapper hitch and the tractor. It will ensure residual controllability of the Bale Wrapper if the machines get uncoupled abruptly.
- Put the panel with the control levers (E) in the tractor's cab.
- Connect the hydraulic supply system by plugging the supply hose plug (A) and the return hose (B) in the supply sockets of the hydraulic tractor.
- If the Bale Wrapper is supplied with the hydraulic rotary-axle shaft-adjusting set, connect its wires (5) to the next hydraulic section of the tractor.
- Adjust the support foot and set it to the transporting position.
- Before you start working or entering public roads, ensure the ground-wheel bolts are tightened correctly.
- Before you enter public roads, connect the Wrapper's lighting system (Section 2.5) to the socket in the tractor. Check the road lighting for correctness. Check the axle shaft for locking in position.
- Start the tractor's, switch on the control panel and check the correct operation of the power hydraulic systems, without the bale and without film in the feeder (Section 4.5).

**CAUTION****CAUTION!**

While connecting with the tractor, position the machine along the tractor's axis on paved, even, and level ground. Stop the tractor's engine, take the key from the ignition and engage the tractor's auxiliary brake.

Set the proper level of the hitch by selecting the correct adjustment eye to level the Bale Wrapper.

2.3.2 Drive disconnection

The Bale Wrapper's and tractor's uncoupling procedure

- Make sure that in the area of Bale Wrapper's coupling with the tractor and in the near vicinity there are no bystanders present, children in particular.
- If it is possible, set the Bale Wrapper's components in the transporting position.
- If the Bale Wrapper is to be idle for a longer time, lower the loading arm, or fit a lock to the same.
- Position the Bale Wrapper in its storage place on even and level ground.
- Stop the tractor's engine, take the key from the ignition, and engage the tractor's auxiliary brake.
- Disconnect both the power supply and lighting systems, wind up the wires, and put them away under the spare film-roll containers.
- Disconnect the power hydraulics system and protect the hydraulic hoses in their clamps on the Bale Wrapper frame (**Fig. 61**).
- Put the panel with control levers of the Bale Wrapper in a holder on the pole of the machine's film feeder.
- Lower the support foot from its transporting position to the working position.
- Make sure that there is no hazard of accidental machine displacement and place a wheel chock if necessary.
- Disconnect the drawbar eye from the transporting hitch of the tractor. Detach the additional chain which links the hitch with the tractor (**Fig. 9 – 4**).
- Fit the drawbar eye with the protection against unauthorised use (**Fig. 10 – 1**).



CAUTION

CAUTION!

Hydraulic connections must be always kept clean. After use reinstall the plastic cover supplied with the machine purchase.



CAUTION

CAUTION!

After disconnecting the Wrapper from the tractor, its control panel should be stored in a dry, safe, place, away from reach of unauthorised persons, especially children.



CAUTION

CAUTION!

After disconnecting the Bale Wrapper from the tractor, wind up and store its power-supply wires and the communication cables of the control panel under the hydraulic manifold.

2.4 Drawbar components




Figure 10. Drawbar components

Key for the Z577 Bale Wrapper-drawbar components (**Fig. 10**)

1. Chain with a padlock and key set (protection against unauthorised use of the machine)
2. Chain with a connecting shackle (additional protection against combination detachment)
3. Left drawbar arm
4. Right drawbar arm
5. Hitch with swivel eye

2.5 Lighting system




Figure 11. System wiring diagram

The Bale Wrapper is equipped with a 12V road-lighting system connected to the tractor's system by means of the 7-pin plug, ISO 1724 Type N (**Fig. 11 – A**). The tractor must be fitted with a socket which is suitable for the plug (**Fig. 11 – B**).




Figure 12. Wrapper-lighting plug (socket side view)

Table 4. Description of the plug lighting wires (**Fig. 12**)

No. of pin	Marking	Circuit description
1	L	Left indicator
2	54G	Fog lights
3	31	Equipotential frame
4	R	Right indicator
5	58R	Right position lamps
6	54	STOP
7	58L	Left position lamps

2.6 The hydraulic system

The Bale Wrapper's hydraulic installation is supplied from the tractor's power hydraulics system. Connecting to the power hydraulic system is achieved by connecting the hoses supplying the hydraulic distributor, and further on, the hydraulic motor and hydraulic servos (cylinders). The individual hydraulic components are connected to one another with flexible and metal hydraulic hoses.

Depending on the version, the Z577 Bale Wrapper features a power hydraulic system (**Fig. 13, 14**), consisting of the following parts.

1 – Control levers, 2 – Hydraulic manifold, 3 – One-way flow-control valve, 4 – Hydraulic motor for turntable, 5 – Cylinder for locking the service table, 6 – Cylinder for raising and lowering the moving frame, 7 – Cylinder for raising and lowering the loading arm, 8 – Non-return valve, 9 – Hydraulic valve of the film cutter, 10 – Hydraulic accumulator, 11 – Cylinder for the film cutter




Figure 13. The hydraulic system of the Z577 Bale Wrapper with hydraulic film cutter




Figure 14. The hydraulic system of the Z577 Bale Wrapper with mechanical film cutter

Control of the hydraulic receivers is implemented via the control-lever panel which is put in the tractor's operator's cab during the time of operation. The control levers are joined with the valves in the hydraulic manifold by means of Bowden cables (two-way action links).

The hydraulic block is protected against too-high pressure in the tractor's power hydraulic system with a pressure valve set by default at 200 bar. The maximum hydraulic oil pressure at which the Bale Wrapper can work is 160 bar.

If the tractor's pump volume of consumption is above 30 l/min, use the tractor's valve to reduce it to 25l/min. If the tractor is not supplied with a flow regulator, have one fitted.



The hydraulic system of the Bale Wrapper was factory-filled with oil type L-HL 46. The tractor's hydraulic system working with the Bale Wrapper must be filled with the same type of oil. Filling the hydraulic system with oil of another type should be consulted on with the manufacturer of the machine.



CAUTION

CAUTION!

Filling the Bale Wrapper with a different volume of oil consumption from that recommended can result in too-abrupt action by the parts of the machine, fast oil overheating, and eventually damaging the parts of the machine. Use flow regulators.




Figure 15. The hydraulic system
1 – 3-section manifold, 2 – Valve, 3 – Control levers

2.7 Start-up



The start-up of a newly-purchased Bale Wrapper is carried out by the distributor's technical department.



CAUTION

CAUTION!

Prior to the start-up of the Bale Wrapper, read this Manual carefully, paying close attention to the sections concerning the safety of the operator and bystanders.



In the event of any uncertainties regarding safety, contact the dealer/manufacturer.



CAUTION

CAUTION!

Before you start operating the machine, read the Instructions Manual and adhere to the guidance herein.

Couple the Bale Wrapper with tractor in good working condition only, and ensure its agricultural hitch, and the hydraulic, 12V electrical and signalling/warning systems are fully operational.



CAUTION

WARNING!

Use special care during the start-up.

Any bystanders in the working area of the machine compromise safety.



CAUTION

CAUTION!

Each time before starting the Bale Wrapper, install the control levers in the tractor's cab.

During the start-up, an employee of the dealer's or manufacturer's licensed service, accompanied by the user (buyer), is to perform the following.

1. Inspect the accessories and functioning of the Bale Wrapper.
 - Check the machine for completeness and good working condition
 - Check the lighting system and horn
 - Check the electrical system.
 - connect the communication cable with the counter
 - connect the supply conductor to the tractor's socket
 - start up the counter (**Section 2.7.1**).
 - Check the hydraulic system.
 - connect the hydraulic hoses to the tractor's, determine the correct direction of the oil flow
 - remove the transporting protections of the bale tipper, reset the machine in the service position
 - make trial actions of the Bale Wrapper service parts, check the functioning of the sensor counting the service-table revolutions
 - set the machine in the transporting position
2. Train the user on the correct Bale-Wrapper operation.
 - Discuss the rules of the Wrapper's operation
 - Film installation
 - Discuss the design and functioning of the control-lever panel
 - Discuss the risks which can arise from improper Bale-Wrapper operation
 - The Wrapper's adjustable components
 - adjusting the hitch height
 - the method of resetting the axle shaft of the rotary Bale Wrapper to the transporting and service positions
 - adjusting the height and angle of film-feeder rotation
 - adjusting the film feeder for 500-mm and 750-mm film
 - adjusting the chain tension on the chain drives of the film feeder, service table, and service-table roller
 - adjusting the film cutting/grabbing device
 - adjusting the throttle/non-return valve for the service-table locking device
 - adjusting the throttle/non-return valve for the raising unit of the bale tipper
 - adjusting the throttle/non-return valve for the lowering unit of the bale tipper
 - Discuss the method of lubrication and ongoing Bale-Wrapper maintenance
 - Perform a full cycle of the bale film wrapping by the user (buyer) assisted by the service technician
 - Perform the procedure of resetting the Bale Wrapper in the service and transporting positions, including preparing the machine for riding on public roads

2.7.1 Counter start-up

Install the wrapping counter in the tractor's cab. Connect it to the revolution sensor and use a power cord to connect it to the power supply.

A red light will flash on the counter display to confirm a correct connection.

Press and hold the "ON" button (symbol C)

Each time the counter is switched on, the display and power supply are tested. The display will show 8888, all decimal dots and LED's will be lit, and the device will emit a sound. Then, the display will show the counter's supply voltage, e.g. U12.7 which stands for 12.7V.

Any different counter status means that it is faulty.

Next, the display will show a manufacture date for the counter, e.g. 2011, and a yellow LED (1) will be lit. Use the F2 button to enter the manufacture year for your Bale Wrapper (from 2000 to 2099).

Use the F1 button to move to the serial-number setting for the Bale Wrapper. The serial-number setting mode is confirmed by a lit LED (2). Enter the serial number by pressing and holding the F2 button (from 0000 to 9999).

Verify the data entered is correct by pressing F1. The Bale Wrapper's manufacture year and serial number should be displayed alternately.

Press and hold the "ON" button C for around 10 seconds to confirm the correctly entered data. The red LED will flash, and the sound will be generated alternately, to confirm that the data have been entered successfully.

You can enter the manufacture date and serial number only once. Once confirmed, you can't enter any more data.

To stop entering data, unplug the counter from the power-supply voltage. The wrap counters cannot delete or make changes to data.

3. Ongoing control and adjustment components



CAUTION

CAUTION!

Before you start the operation and adjustment works, ensure you switch off the tractor's hydraulic system, stop the engine, take the key from the ignition, and engage the tractor's auxiliary brake.

3.1 The arrangement of the ongoing adjustment controls




Figure 16. Ongoing adjustment components

- 1 – Control levers, 2 – Film feeder, 3 – Support foot, 4 – Hitch-height adjustment, 5 – Front lighting, 6 – Rotating axle shaft, 7 – Loading-arm lock, 8 – Revolution-counting sensor, 9 – Service-table chain drive, 10 – Roller-chain drive, 11 – Film-feeder chain drive, 12 – Film cutter, 13 – Valve for locking the service table, 14 – Bale-tipper valve adjustment, 15 – Film-roll adjustment, 16 – Loading-arm width adjustment, 17 – Angle gearbox

3.2 Control levers



CAUTION

CAUTION!

Each time before starting the Bale Wrapper, install the control levers in the tractor's cab.




Figure 17. Pictograms on the control lever panel.

A – table revolution

B – raising and lowering the turntable, C – raising and lowering the loading arm



CAUTION

CAUTION!

When controlling the Bale Wrapper, follow the principles below to move the levers: try to start and finish the movements of the machine's working parts smoothly. Sudden and reckless movements can result in machine damage.

The control-lever panel is fitted with a clamp for securing it in the tractor's cab. Fix the lever panel firmly so that it does not hamper driving the tractor or make the use of the control levers during difficult operations.



CAUTION

CAUTION!

Take time! If you are a beginner at Bale-Wrapper operation, always check the pictogram if the lever matches the action you want to activate.

3.3 Film feeder




Figure 18. Film feeder

1 – Film roll, 2 – Pre-stretchers, 3 – Upper clamp, 4 – Lower clamp, 5 – Jam nut, 6 – Film-flow sticker, 7 – Pre-stretching gear, 8 – Hook securing a bracket, 9 – Height-adjustment bolt, 10 – Setting screws for feeder angle

The film feeder is a device which feeds a band of film to be wrapped around a bale which is rotated on the turntable. A 500- or 750-mm film roll is placed in a rotary position, contained in a feeder frame, between the upper and lower clamps. The band of film is unwound between the pre-stretchers, which stretch the film from the beginning of the wrapping process. The ratio on the chain drive between the roller near the roll and the outer roller is 1.75.

The film should be pre-stretched at 70-80% but it can vary due to different types and properties of films.

3.4 Support foot




Figure 19. Support foot of the Bale Wrapper

The support foot features two adjustment levels (**Fig. 19**), 1 – A non-step adjustment of the level of support within 340 mm changed with a handwheel (crank), 2 – A three 90-mm step adjustment, set with a handwheel.



CAUTION

CAUTION!

Use the step adjustment of the support foot only when the Bale Wrapper is connected to the tractor's hitch.

Loosening the setting handwheel when the drawbar is not supported can result in crushing.

When the machine is not coupled with the tractor, the support foot is used to prop the machine firmly. Use it to level the Bale Wrapper when coupling the machine with the tractor.

3.5 Adjusting the hitch height




Figure 20. Adjusting the hitch height

The Bale Wrapper hitch is supplied with four height settings - 375, 515, 650 and 780 mm above the ground.

Follow the adjustment procedure (**Fig. 20**).

- Position the tractor as closely as possible to the hitch eye of the Bale Wrapper.
- Level the Bale Wrapper against the ground using the support foot.
- Loosen the M20 nut (**1**) which locks the hitch eye in place.
- Loosen the M20 nuts (**2**) on the bolts which are rotary pins of the drawbar mounted on the main frame.
- Unwind the M20 nuts (**3**) on the bolts which set the height of the drawbar, and remove the bolts.
- Set the drawbar to the required height by slotting the bolt into a proper hole – positions A, B, C or D.
- Set the hitch eye to the horizontal position by turning it on the curved link.
- Secure the hitch-eye connection by tightening the nut and bolt (**1**) to a torque of 400 Nm.
- Secure the connection of the drawbar and the Bale Wrapper's frame by tightening the nuts and bolts (**2**) and (**3**) to a torque of 400 Nm.

3.6 Shifting the ground-wheel position

The right axle shaft of the Bale Wrapper can be set in two positions, i.e. set internally for transportation and set externally from the machine for service.

The transporting position ensures that acceptable dimensions of the machine during transportation are met.

The service position ensures the required stability of the Bale Wrapper during operation in the field.

Changing the positions is only allowed if no bale is loaded on the Bale Wrapper.

3.6.1 Unlocking the axle shaft's position




Figure 21. Unlocking the axle shaft's position

- Remove the locking pin (1) which secures the foot pin (2).
- Pull the eye of the pin upwards to remove it (3).
- Put the pin with its locking pin away in the tractor's cab.

3.6.2 Locking the axle shaft's position




Figure 22. Locking the axle shaft's position

- Slot the pin (1) downwards into the lock holes of the axle shaft.
- Ensure the pin is inserted fully until it is stopped (2).
- Secure the pin with a locking pin (3) to prevent its detachment.

3.6.3 Ground-wheel-servicing position




Figure 23. Shifting the drawbar from the transporting to working position

If the Bale Wrapper is supplied with the hydraulic drawbar adjusting set, see **Section**

3.7

Shift the ground wheel to working position (**Fig. 23**)

- Park the tractor with the Bale Wrapper on level and solid ground as far as it is possible. Ensure there is enough space for manoeuvring the combination.
- Remove the locking pin which secures the pin which locks the axle shaft (**Section 3.6.1**).
- Remove the pin (1) and put it away in the tractor during the axle shaft's shifting task.
- Drive the tractor slowly forwards (2) while turning slightly left until the axle shaft is set perpendicularly to the driving centre line (3).
- Then, reverse the tractor slowly (4), while turning its wheels slightly right until the axle shaft starts shifting to the service position (5).
- Once the axle shaft has reached its extreme position, switch off the tractor and apply the auxiliary brake.
- Fit the pin to lock the axle-shaft position and secure it with the locking pin (**Section 3.6.2**). Should any problem occur in terms of the axle shaft's failing to turn, roll the ground wheel manually on a solid ground.

3.6.4 The ground wheel's transporting position




Figure 24. Shifting the drawbar from the working to transporting position

If the Bale Wrapper is supplied with a hydraulic drawbar adjusting set, see **Section 3.7**

Shift the ground wheel to the transporting position (**Fig. 24**)

- Park the tractor with the Bale Wrapper on level and solid ground as far as is possible. Ensure there is enough space for manoeuvring the combination.
- Remove the locking pin which secures the pin which locks the axle shaft.
- Remove the pin and put it away in the tractor during the axle-shaft shifting task.
- Drive the tractor slowly forwards while turning slightly left until the axle shaft is set perpendicularly to the driving centre line.
- Then, reverse the tractor slowly (4) while turning its wheels slightly left until the axle shaft starts shifting to the transporting position.
- Once the axle shaft has reached its extreme position, switch off the tractor and apply the auxiliary brake.
- Fit the pin to lock the axle shaft position and secure it with the locking pin.



CAUTION

CAUTION!

Exercise extreme caution when shifting the ground-wheel position. Ensure that there are no bystanders around and that there is enough space left for manoeuvring the tractor and Bale Wrapper.

3.7 The ground wheel's hydraulic shifting set

The Bale Wrapper can be fitted with an additional set as an option which is used to shift the ground wheel hydraulically to the transporting and service positions.




Figure 25. The hydraulic shifting of the ground wheel

Follow the procedure below to shift the ground wheel from the transporting to service position, or the other way round, using the hydraulic cylinder.

- Release the mechanical lock of the wheel position (**Section 3.6.1**)
- Connect the plugs which supply the cylinder to the tractor's power hydraulic section.
- Start the tractor.
- To shift the wheel by 180°, drive slowly forward and use the tractor's manifold lever to shift the Bale Wrapper's wheel to the extreme position.
- Then, reverse the tractor and use the manifold lever to pull the axle shaft into the position which allows the locking of the setting.
- Set the manifold lever in the neutral position, switch off the tractor's engine, apply the auxiliary brake.
- Secure the axle shaft position using the lock pin (**Section 3.6.2**).



CAUTION

CAUTION!

Always lock the setting with the pin when you shift the ground wheel to a position you have selected.

3.8 Adjusting the bale tipper's width




Figure 26. Adjusting the bale tipper

The bale tipper is fitted on its support frame and its position can be adjusted. In the service position, set the unit in the adjustment area, which is marked out by the symmetry axis of the service table and the extreme point on the beam it is mounted on, at the rotating-axle shift side (**Fig. 26**). To shift the bale tipper

- Remove the clamp for the tipper body (1).
- Shift the tipper to a position you selected, which is in the bounds of the adjustment area (2).
- Secure the chosen position by tightening the clamp of the tipper (1).
- Set the tipper to the service position and unload a bale to ensure the tipper is functioning properly, if necessary. The bale should land on the bottom cradle.

3.9 Adjusting the height of the revolution-counter sensor

Follow the sensor-adjustment procedure.

- Loosen the bolts which lock the sensor and set its setting to the lowest-level possible.
- Start the tractor, position the service table so that the activating magnet is over the sensor.
- Switch off the tractor's engine, set the hydraulic manifold levers to neutral and apply the auxiliary brake.
- Turn the power supply on for the L-02 counter, turn the counter on and set it to the revolution-counter mode.
- Set the sensor at a distance to the magnet to enable pulse counting; usually it is 10-15 mm. Each pulse is signalled by a short sound from the counter.
- Fit the sensor in the correct position using the sensor's nuts.
- Put the counter panel in the tractor, start the tractor, and turn the table to check the revolutions are being counted on the L-02 counter.

3.10 Adjusting the loading arm's width

The loading arm comes with three adjustment ranges which allow you to customise it to working conditions such as the compaction and diameter of bales to be loaded. Select a width which will allow you to fit the bale between the arms in their lower position when you drive the machine toward it. When raising the bale, the arms must grasp the bale firmly and it should roll into the service table freely without any obstruction from the arm in its raised position.




Figure 27. Changing the loading arm's width

Changing the loading arm's width (**Fig. 27**).

- Lower the loading arm
- Unwind the nuts (1) and remove the bolts (2) which retain the external arm (3) in its position.
- Set a new position for the external arm by moving it in and out so that it could be locked with the bolts at one of three pairs of set holes.
- Secure the new position by slotting the bolts through the set holes and tightening their nuts.

3.11 Adjusting the tension of the chains

Two chain drives are designed in the Bale Wrapper to drive the service table and rollers, and one chain drive for correct ratio of the pre-stretchers in the foil feeder.



A routine inspection of chain tension must be performed after wrapping 120 bales.




Figure 28. Chain-tension adjustment – determining a chain bend: f – chain-bend value, L – distance between the sprocket-centre lines
 $f = 0.1 \times L$

3.11.1 Adjusting the drive-chain tension for the service table




Figure 29. Drive-chain adjustment
 1 – Chain guard, 2 – M12 nuts, 3 – Chain-tensioner bolt

Two chain drives are used for the Bale Wrapper's turntable and rollers. Tension the drive chains after wrapping the first 10 bales (**Fig. 29**).

- Dismount the chain guard (1)
- Loosen the 4 M12 nuts (2)
- Tighten the M12 bolt for the chain tensioner (3) so that it results in a 20 mm bend of the chain
- Tighten the 4 M12 nuts (2)
- Install the chain guard

3.11.2 Adjusting the drive chain for the rollers of the service table




Figure 30. Dismount the guard of the roller-drive chain




Figure 31. Adjust the tension of the roller-drive chains

Follow the procedure below to adjust the chain tension in the drive of the service table rollers (**Fig. 30**, **Fig. 31**).

- Unwind the M12 nuts (1) which lock the guard (2) and open it.
- Loosen the M12 nuts (3) which lock the sliding bushes of the tensioners in place.
- Use the adjustment nuts (5) to set the correct tension of the drive chains.
- The correct tension is characteristic of a chain bend of 10–15 mm.
- Once the chain tension is set, tighten the locking nuts (3).
- Replace the guard (2) and secure it by tightening its nuts (1).



For the hydraulic film-cutter version, the roller-drive chain is on the opposite side of the service table and mirrors the Bale Wrapper's drive chain in the mechanical film cutter.

3.11.3 Adjusting the film feeder's chain drive




Figure 32. Dismount the guard of the feeder-chain drive




Figure 33. Adjust the tension of the feeder-drive chain

Follow the procedure below to adjust the chain tension in the drive of the service-table rollers (**Fig. 32**, **Fig. 33**).

- Unwind M8 bolts (1) which lock the drive guard (2) and open it.
- Loosen the M12 nut (3) which locks the tensioner (4) in place
- Shift the tensioner left so that the chain bend at point (A) is 5-10 mm
- Once the chain tension is set, tighten the locking nut (3).
- Replace the guard (2) and secure it by tightening its bolts (1).

A correctly tensioned chain of the drive will enable the smooth rotation of the film pre-stretchers. If the rotation of the rollers is obstructed or blocked, it can be caused by excessive tension in the drive chain.

3.12 Adapting the wrapping for 500-mm film

The Bale Wrapper is factory set to wrap with film of 750-mm width. For wrapping with a 500-mm film, change the sprocket of the roller drive (**Fig. 34**) and adapt the film feeder for the 500-mm film (**Section 3.12.2**).

3.12.1 Adapting the service table's chain drive for 500-mm film




Figure 34. The sprockets of the roller-drive chains

- Unwind the 4 M12 cap nuts, remove the side guard of the rotary frame (on the drive-chain side).
- Loosen the M12 bolts of the chain tensioners.
- Remove both chains from the Z-27 sprocket installed on the main shaft and remove the pin which locks this sprocket in place.
- Dismount the Z-27 sprocket from the shaft using a proper extractor.
- Dismount the Z-17 sprocket from the spare sprocket bar, replace it with the Z-27 sprocket and secure it with a pin.
- Mount the Z-17 sprocket onto the drive shaft.
- Secure the Z-17 with a pin, mount the chains, and adjust their tension.
- Fit the side cover.

3.12.2 Adapting the feeder for 500-mm film

- Remove the M12 nut from the bolt which locks the upper clamp spindle, and remove the locking bolt.
- Lower the upper spindle so that its adjustment hole is aligned with the locking hole in the locking bushes.
- Lock it into place again by fitting the locking bolt and lock it in place by tightening the M12 nut on it.
- Tighten the lower clamp shaft using the crank provided at a height which enables the mounting of the 500-mm film roll.

3.13 Adjustment valves

The hydraulic system of the Bale Wrapper is supplied with throttle/non-return valves, used for setting the speed of cylinder action. These valves have factory settings, but as the Bale Wrapper continues to be operated, readjustments might be necessary.

Before adjusting, switch off the tractor's engine, apply the auxiliary brake, and take the key from the ignition.

Before adjusting the throttle/non-return valve, turn it off and count the number of handwheel turns while doing so. This will ensure the factory setting. It is advisable to take note of the values to return to the factory settings easily.

While adjusting, turn the valve handwheel off and on by half a turn compared to the factory setting, depending on whether you want to slow down or accelerate cylinder action.



CAUTION

CAUTION!

Never adjust the valves while the tractor's engine and power hydraulic system are working.

Once the valve is set, check the functioning of a selected section, and if the result is not satisfactory, turn the valve handwheel off, or on by another half a turn.




Figure 35. Throttle/non-return valve, 1 – Valve handwheel, 2 – Valve shell marked for the throttling direction, 3 – Throttled-flow direction, 4 – Free-flow direction

The valve design facilitates throttling the oil flow to be set in one direction, marked on the valve shell. Throttling does not apply in the opposite direction.

3.13.1 The adjustment valve for the turntable lock




Figure 36. The location of the adjustment valve for the service-table lock

The locking pin of the service table should move out during reverse-table revolutions, which is opposite to the wrapping direction. Locking the table is described in **Section 4.5.2**.

If the locking pin fails to move out, turn the valve handwheel (**Fig. 36 – 1**) by half a turn and check the locking action. Repeat if necessary.

If the locking pin moves out too quickly or it falls out after the control lever is released, turn the valve handwheel by half a turn and check the locking action. Repeat if necessary.



CAUTION

CAUTION!

When locking the service table, move the control levers smoothly and avoid sudden movements with the control lever. Locking the service table too abruptly can damage the locking unit.

3.14 Adjusting the mechanical film-cutting device

The correct method of mechanical cutter operation is described in **Section 4.5.4. Film cutting**




Figure 37. Enclosed film cutter A – back view, B – front view




Figure 38. Open film cutter A – back view, B – front view

Adjusting the position of the film-cutter arm (**Fig. 37, 38**)

- The film cutter arm (1) in its closed position must be set so that it retains the clamping position (2), and when the service table revolves, the lower part of the arm is able to hit the film cutter buffer (**Fig. 58 – 8**).
- Adjust the arm's position by tightening or loosening the bolt of the end stop (3).
- The open position of the film cutter is defined by its clamping-link length (4).

Adjusting the film cutter's clamping force (**Fig. 37, 38**)

- The clamping surfaces (2) in the closed position must be flush with each other.
- The ear of the clamping device in the open position, which connects the clamping device (2) with the link (4), must rest on the end stop (5).
- The clamping force is to be adjusted by using nuts (6) to tension the spring on the link.
- The clamping position is to be adjusted by using a nut (7) to change the link length.

Adjusting the cutting blade (**Fig. 37, 38**)

- The edge of the moving blade (8) in the closed position must be set in parallel to the edge of the fixed blade (9).
- In the open position, the angle between the blade edges must be bigger than the angle of the clamping area, so that the film band is not damaged too early when it is pulled to the clamping device.
- Use the handwheel (10) on the blade link (11) to adjust the angle between the fixed and moving blades.
- Use the set screws (12) to set the clamping force of the fixed and moving blades.



DANGER

DANGER!

Exercise particular caution when adjusting the blade. The blade is very sharp. Risk of hand injury.

3.15 Adjusting the hydraulic film-cutting device

The hydraulic film-cutting unit is driven by a cylinder whose rod is fitted with a film-clamping device. When grabbing the film, the oil pressure from the line supplying the service table dumping drives the cylinder rod of the cutter to move out.

The hydraulic accumulator, fitted at the cylinder rod's side, drives the cutter back to its open position.

The hydraulic accumulator must be filled with oil with an initial pressure of 40-45 bar when the cutter is in its open position.

3.15.1 Adjusting the cutter height




Figure 39. Adjusting the cutter height

The film cutter is set in its highest position by default. Lowering the film cutter (**Fig. 39**).

- Unwind the M12 nuts (1) of the side covers and remove the covers (2).
- Loosen the nuts on the M12 bolts (3) which fasten the cutter frame to the service table.
- Lower or raise the cutter frame to your selected position (4) and secure it in this position by tightening the nuts (3).
- Mount the covers (2) and secure the M12 nuts (1).

3.15.2 Adjusting the film cutter's activation position




Figure 40. Film-cutter activation module – the closed-cutter position

Changes to the length of the activating wire to adjust the position in which the cutter's activation module will remain in its closed position (**Fig. 41 – 1**). Shorten the wire to set the early activation of the cutter, and extend it to set its late activation.

By default, the cutter closes when the moving frame reaches its maximum tilt.




Figure 41. The location of the wire-length adjustment




Figure 42. The film-cutter activation module – the open-cutter position

3.15.3 Filling the hydraulic accumulator



CAUTION

CAUTION!

Carrying out the procedure for filling the hydraulic accumulator without operational pressure gauge on the supply line is not allowed.



CAUTION

CAUTION!

Having two persons who know the cutter's principle of operation and its filling method carry out the filling procedure is recommended.

To fill the hydraulic accumulator, prepare a hydraulic hose terminated with a quick coupling plug at one end and a socket at the other (ISO 7241-1). Prepare the pressure gauge calibrated to at least 140 bar, which is suitable to be connected to a Minimes M16x2 measuring connection (ISO 8434-1 / DIN 2353), or a pressure gauge connected to a tee terminated with a quick-coupling plug and socket. The tractor fitted with a hydraulic manifold with can be a supply source if it comes with valve-opening adjustment (lever) or supply-pressure adjustment.

Follow the procedure below to fill the hydraulic accumulator with oil.

- Connect the initial hose from the Bale Wrapper's manifold to the socket in the tractor hydraulic section
- Connect the hose which supplies the hydraulic accumulator you prepared to the plug under the cutter cylinder and to the tractor's section socket
- Connect the pressure gauge to the measuring connection The gauge can also be connected to the line supplying the cylinder
- A ball valve under the cylinder must be in the open position. Set the cutter-activation module in the position, as in **Fig. 42**
- Have one person turn the tractor's hydraulic supply on and off and the other person turn the cutter ball valve off
- Start the tractor's engine, and, as soon as the person operating the ball valve issues a signal, start the hydraulic supply of the supply section slowly
- When the pressure gauge shows a pressure of 40-45 bar, the ball-valve operator turns the valve off and issues a signal for turning off the tractor's hydraulic system
- Stop the engine and use the manifold lever to reduce the pressure of the supply system, disconnect both the hose supplying the hydraulic accumulator and the pressure gauge
- Connect the supply hose of the Bale Wrapper and check the cutter's functioning
- If the accumulator is filled with too-high or too-low pressure, first connect the hose supplying the cylinder and open the ball valve of the cutter to discharge the pressure to the tractor's hydraulic system, and then repeat the filling procedure

3.16 The front-lighting transporting and servicing positions

To avoid any risk of damaging the road lighting during operation, front lighting can be folded to the service position, where it is out of reach of the moving parts of the Bale Wrapper.




Figure 43. The front-lighting-transporting position A – right side, B – left side




Figure 44. The front-lighting-service position A – right side, B – left side

Setting the working position of the front lighting (**Fig. 43, 44**)

- Loosen the knobs (1) and move the brackets of the reflective lights (2) towards the position light. Use the knob to lock the position.
- Remove the pin which locks the light bracket in place (3) and set the bracket to the servicing position (4).
- Use the pin with its locking pin to secure the position.
- Carry out the same procedure for the left and right sides.

Preparing the lighting for the transporting position.

- Remove the pin which locks the light bracket in place (3) and set the bracket to the transporting position.
- Use the pin with its locking pin to secure the position.
- Loosen the knobs (1) and move the reflective light brackets until they are stopped (2). Use the knob to lock the position.
- Carry out the same procedure for the left and right sides.

INDEX OF NAMES AND ABBREVIATIONS

A – Ampere, electric-current unit

Bar – bar, pressure unit (1 bar = 0.1 MPa)

OS&H – occupational health and safety

dB (A) – decibel A, sound-pressure unit

Drawbar pull class – a value characteristic for the drawbar pull of a tractor's, class 0.9 corresponds to a drawbar pull of 9 Kn. The Ursus C 355 and 4011 tractors have this pull class.

kg – kilogram, weight unit

km/h – kilometre per hour, linear-speed unit

kW – kilowatt, power unit

m – metre, length unit

mm – millimetre, an auxiliary length unit equal to 0.001m

min – minute, an additional time unit corresponding to 60 seconds

rev. – revolution, a type of movement

rpm – revolutions per minute, rotation speed unit

Pictogram – a notice plate

Fig. X – a figure with a number "X"

Fig. X, Y – figures with numbers "X" and "Y"

Fig. X-Y – a figure with a number "X", item in the figure "Y"

Tab. X – a table with a number "X"

Rating plate – a manufacturer's plate unambiguously identifying the machine

UV – ultraviolet radiation, invisible electromagnetic, invisible electromagnetic radiation with negative effects on human health; UV radiation has a negative effect on rubber parts

V – Volt, a voltage unit

Hitch, upper transporting hitch – hitch components of a farm tractor's (see the tractor's Instructions manual)

ALPHABETICAL INDEX

PART I

A

Adjustment valves 53-54

B

Bale tipper 47

C

Chain 49-51

Control levers 39

Control panel 39

D

Design, Bale Wrapper 15

F

Film cutter 55-59

Film feeder 40

G

Ground wheel 43-46

H

Hazard-warning symbols 20-22

Hydraulic system 33-34

I

Identification, Bale Wrapper 11

Intended use, Bale Wrapper 14

L

Lighting 32, 60

Loading arm 48

O

Oil 34, 53, 59

P

Pictograms 19

R

Rating plate 11

S

Safety principles 23

Start-up 35

T

Technical characteristics 16-17

W	
Wrapping	14, 52
PART II	
A	
Accessories	46
B	
Bale loading	17
Bale unloading	20
C	
Cleaning	28
D	
Disassembly	42
F	
Faults	43-45
Film clamping	8
Film cutting	22-24
L	
Lubrication	30, 32
Lubrication points	33
M	
Maintenance	30
N	
O	
Oil	30
R	
Risk	41
Road traffic	35-39
S	
Service	34
Scheduled inspections	30
Storage	40
T	
Transporting	35
Transporting position	26
W	
Wrap Counter	9-12
Wrapping	18

NOTES

A series of horizontal dotted lines for taking notes, spanning the width of the page.

A series of horizontal dotted lines spanning the width of the page, providing a template for handwritten notes or a checklist.



Since Metal-Fach Sp. z o.o. is continuously improving its products, and adapting its product range to fit the customers' needs, we reserve the right to modify our products without prior notice. Therefore, we advise contacting an authorised dealer or sales representative of Metal-Fach Sp. z o.o., prior to making your decision about purchase.

Metal-Fach Sp. z o.o. will not accept any complaints regarding the data and pictures contained in the catalogue, as the presented range of products does not constitute an offer within the meaning of the provisions of the Civil Code.

The pictures do not necessarily show standard accessories.

Original spare parts are available from authorised dealers, both in Poland and abroad, and also at the Metal-Fach retail outlet.

TECHNICAL SERVICE

16-100 Sokółka, ul. Kresowa 62
Tel.: +48 85 711 07 80; Fax: +48 85 711 07 93
serwis@metalfach.com.pl

SALES

16-100 Sokółka, ul. Kresowa 62
Tel.: +48 85 711 07 78; Fax: +48 85 711 07 89
handel@metalfach.com.pl

SPARE PARTS WHOLESALE STORE

16-100 Sokółka, ul. Kresowa 62

Wholesale:

Tel.: +48 85 711 07 81; Fax: +48 85 711 07 93
serwis@metalfach.com.pl

Retail

24/7 PHONE: +48 533 111 477
Tel.: +48 85 711 07 90

CURRENT INFORMATION ON OUR PRODUCTS CAN BE FOUND ON WWW.METALFACH.COM.PL

